

DishTemp[®] dishwasher thermometer

- displays maximum temperature reached
- simulates plate surface temperature

The new DishTemp thermometer simulates a plate as it's cleaned and sanitised in a commercial dishwasher, accurately recording the maximum surface temperature at the touch of a single button. The DishTemp eliminates the need for costly and inaccurate test strips and stem thermometers that don't stay in place and don't record temperature at the plate surface.

Built to survive daily use in professional kitchens, the DishTemp thermometer indicates temperature over the range of 0 to 90 °C with a resolution of 0.1 °C/°F and an accuracy of ±0.5 °C.

Incorporating a durable water-tight seal, the DishTemp is waterproof to IP66 and is supplied complete with a traceable certificate of calibration.

order code	description
810-280	DishTemp thermometer



specification	DishTemp
range	0 to 90 °C
resolution	0.1 °C/°F
accuracy	±0.5 °C
battery	3 volt CR2032 lithium coin cell
battery life	5000 hours
display	custom LCD
dimensions	14 x Ø127 mm
weight	120 grams
FREE traceable certificate of calibration included	

