

Fridge or Freezer thermometer with alarm & max/min functions

Fridge Freezer Thermometer Max/min digital fridge freezer alarm thermometer that indicates temperature over the range of -49.9 to 69.9°C.

This fridge thermometer features a large LCD display, a max/min memory function to record the highest and lowest temperatures and an audible alarm. This fridge thermometer incorporates two temperature sensors, a remote water resistant probe with a one metre PVC lead for the appliance temperature, and an internal sensor for the room temperature. The external probe can be mounted onto the fridge internal wall using the suction pad or mounting bracket supplied.

The thermometer is housed in a robust ABS case and incorporates a foot-stand for shelf mounting..



Technical specification

range	-49.9 à 69.9°C
Resolution	0.1°C
Accuracy	± 1 C
Battery	1.5 Volts AAA
Battery life	5000 hours
Display	custom LCD
Dimensions	15 x 52 x 73 mm
weight	48 gram
Case material	ABS plastic
Alarm	Adjustable alarm
Max / Min function	yes
Probe /Sensor style	internal & external fixed sensor
Calibration	3 points UKAS certificate optional